

This for
Clarity on EX-ia

--

Ex ia is intrinsic safety. You have no electronics, therefore your product is not Ex ia. Someone can use your enclosure with Ex ia electronics and apply for Ex ia marking for the end product. But by itself, an empty enclosure is not and cannot be Ex ia.

Marlon Mitchell | Senior Engineer
FM Approvals | 743 Reynolds Road | West Glocester, Rhode Island, 02814 USA
T: 401.567.5018 | **F:** 401.568.6241 | **E:** marlon.mitchell@fmapprovals.com